

**Product Name :**  
Pipe Friction Apparatus**Product Code :**  
FUDE0037**Description :**

Pipe Friction Apparatus

**Technical Specification :**

1. Prepare the equipment and water source and close the inlet ball valve.
2. The interface between the inlet pipe and the test pipe.
3. Test management pressure measurement interface and tube pressure gauge interface connection.
4. Connect the water source to the water inlet and connect the water outlet of the corresponding test line to the appropriate container.
5. Open the inlet ball valve, the water flows through the DN15 elbow, observe the flow value on the flow meter and the pressure value of the corresponding measuring point on the tube pressure gauge, and record the data.

