

Common Uses:-

The LM Arbors are mounted on machine Spindles, supported brackets.

The bearing bushes provided on the Long Milling Arbors fit into the brackets.

The LM Arbors are meant for use on horizontal Milling Machines and universal Milling Machines to mount Milling Cutters.

The spacers provided on the LM Arbors are for mounting cutters at required positions.

The draw bar arrangement in the Spindle allows the LM Arbor to fit firmly.

Scope of Supply:-

The length of the LM Arbors to suit machine specifications can be set with brackets.

Unless specified otherwise, the LM Arbors have RH threads at the end of tightening.

A full set of LM Arbor comprises bearing bushes, spacers, nut, and keys, supplied.

The LM Arbors are available with ISO 30, 40 and 50 tapers.

Also, special Tapers - BT and Morse Tapers are available.

For specific requirements, LH threads can be provided.

The LM Arbors ensure 0.015mm to 0.030mm concentricity, as per IS specifications.

Selection and Ordering:-

To select LM Arbors consider the following points:-

The Taper of the LM Arbor - BT of Morse Taper to be decided based on the machine spindle specifications.

The length of the LM Arbor - 100mm to 800mm to be decided as per the permissible length that can be obtained at the milling Milling machine Brackets is as advisable to use short length LM Arbors for better performance.

For Clockwise / RH rotation, LH threads will avoid loosening of the LM Arbor; similarly RH threads for anticlockwise / LH rotation.

The end- tightening threading to be specified RH or LH threads depending on Clockwise / RH or anti Clockwise / LH rotation of the machine spindle.

To order the right size of LM Arbor specifies the Taper, Length, threading required.

## **▲ A**LTEC<sup>™</sup>

## **Equipments Exporters**

Website: www.equipmentsexporters.com, Email: sales@equipmentsexporters.com Address: 75, Lajpat Nagar-IV, New Delhi-110024 Phone: +91-9311469084